

Termidor HE Copack use in Oklahoma



- Oklahoma has “Minimum Standards” regarding termiticide treatments
- See ODAF’s: Combined Pesticide Laws & Rules (<http://www.oda.state.ok.us/cps-pesticide.htm>)
- ODAF Requirements
 - Trench: Must be 6” deep by 6” wide
 - Rod hole and down drill spacing must be 12” or less
 - Basements: treat down to footer or minimum of 4 ft deep
- HE Label directions-for-use supported in OK include:
 - 2 gallons / 10 linear ft / 0.125%
 - 2 foot deep minimum treatments on deeper foundations that are not basements



TERMIDOR[®] H·E
HIGH-EFFICIENCY TERMITICIDE COPACK
WITH TERMIDOR[®] HE TECHNOLOGY